

# Providing Repeater Facility for any GUIDE System

# **Product Overview**

- Syncro GUIDE Repeater is an additional facility for the Syncro GUIDE fire alarm management system.
- GUIDE Repeater allows control and monitoring of the Syncro fire control system to be repeated on dedicated computers connected to the building Local Area Network.
- GUIDE Repeater is highly configurable allowing replication of the main GUIDE system or alternative information to be given at the repeater

# **Features**

- Up to 16 GUIDE Repeaters may be connected to a single GUIDE system
- All control and monitoring options on GUIDE are supported on the GUIDE repeater
- Choice of text, graphics, combined display when an event occurs.
- Easy to use
- Allows graphical information of fire events to be shown at alternative locations
- Unlimited map linking and zoom facility
- Display and control for up to 64-networked Syncro panels





**Specifications** 

# Range

### **Product Code Description**

GR2001 GUIDE Repeater - single repeater package GR2004 GUIDE Repeater - 4 repeater package GR2016 GUIDE Repeater - 16 repeater package

## **Technical**

Hard disk

Graphics

Sound card

**Printer** 

#### **Recommended Minimum** Notes

**Processor** Intel Pentium 1Ghz The faster the better, 2Ghz will provide future proofing. Operating system Windows® XP/Vista Will operate under Windows® 2000 256MB minimum The larger the better. Memory

10GB minimum >20GB would be better.

1024 x 768 16M colours The driver must allow this mode with large fonts. Separate Graphics card with 256MB graphics memory recommended

Any PC sound card Loudspeaker Any PC speakers More convenient if built into PC. Monitor Any that supports above 17 inch minimum recommended, graphics driver the larger the better. (1024 x 768) **Pointing device** Mouse essential

Optional

Parallel port Optional Network One network port

**CDROM** drive Any

**Backup drive CD Writer**  Third button and wheels are supported. Touch screen option supported Any type. Required if parallel printer to be used.

Required for installation of software

and updates. To back up history.

