




CHQ-BS - PROGRAMMING LEAD INSTRUCTIONS

General Description

The enclosed lead must be used for addressing CHQ-BS if they are selected as Wall Sounders.



Operation-Address Setting

To program a CHQ-BS firstly connect the plug of the lead in to the remote programming socket of the TCH-B100 address programmer, and connect the black croc-clip to the C terminal, and the red croc-clip to the L terminal on the Base Sounder. The address can now be programmed in the same way as an ASX range sensor.

Please note that when programming CHQ-BS the maximum address permissible is 254. CHQ-BS/Control Panel instructions should be checked for address range.

Caution

- ❑ Only to be used with Hochiki Loop devices.
- ❑ Do not short croc-clips together.
- ❑ Remove from programmer when not in use.
- ❑ Disconnect Sounders from the loop before programming.

CHQ-BS PROGRAMMING LEAD - PL2



Hochiki Europe (UK) Ltd
Grosvenor Road, Gillingham Business Park,
Gillingham, Kent, ME8 0SA, England
Telephone: +44(0)1634 260133
Facsimile: +44(0)1634 260132
Email: sales@hochikieurope.com
Web: www.hochikieurope.com

Hochiki Europe (UK) Ltd. reserves the right to alter the specification of its products from time to time without notice. Although every effort has been made to ensure the accuracy of the information contained within this document it is not warranted or represented by Hochiki Europe (UK) Ltd. to be a complete and up-to-date description. Please check our web site for the latest version of this document.